

Nodal Ninja 5 w/R-D16 Rotator Spherical Panoramic Tripod Head

Quick Reference Guide

For complete manual visit:
www.NodalNinja.com

For support visit:
www.NodalNinja.com/forum

*Only buy from "authorized resellers."
If buying new from other than an
"authorized reseller," no warranties
or product support are included.*

©2010 Nodal Ninja®



Nodal Ninja 5
w/R-D16 Rotator



shown with EZ-Leveler



2 knobs in $7.5^\circ/2$ holes = 3.75° stops
2 knobs in $10^\circ/2$ holes = 5° stops
2 knobs in $12^\circ/2$ holes = 6° stops
2 knobs in $36^\circ/2$ holes = 18° stops

Features:

Combined specs:

- * Weight = 995gr (2 lb 3oz)
- * Folded size = 205mm x 119mm (4 3/4x8 1/4")
- * Material = Anodized aluminum
- * Base Color = Non-glare black
- * Load Limit = 10kgs (22lbs)
- * Upper Arm 15 degree lock stops

R-D16 Rotator

Mounting threads = 3/8 inch

Diameter of 62mm

Height = 49mm

Premium quality aluminum alloy.

- * Precision CNC machined components
- * Lubricated bearings for smooth rotation
- * Laser engraved markings
- * Detent interval can be changed quickly
- * Knob for locking rotation
- * Retainer wire so you don't lose the knobs
- * Small nadir footprint
- * Fine 2.5 degree rotation markings

16 selectable increments = no. of stops around:

- 2 knobs in 7.5°/2 holes (= 3.75°) = 96 stops
- 2 knobs in 10°/2 holes (= 5°) = 72 stops
- 2 knobs in 12°/2 holes (= 6°) = 60 stops
- 1 knob in 7.5° hole = 48 stops
- 1 knob in 10° hole = 36 stops
- 1 knob in 12° hole = 30 stops
- 1 knob in 15° hole = 24 stops
- 2 knobs in 36°/2 holes (=18°) = 20 stops
- 1 knob in 20° hole = 18 stops
- 1 knob in 24° hole = 15 stops
- 1 knob in 30° hole = 12 stops
- 1 knob in 36° hole = 10 stops
- 1 knob in 45° hole = 8 stops
- 1 knob in 60° hole = 6 stops
- 1 knob in 90° hole = 4 stops
- 1 knob in 120° hole = 3 stops



Portrait



Landscape

NN5's only

